


How to Set Folder Permission in Sub-Folders using File Manager

A. Using default admin account


1. Add Share.




2. Modify permission. Add AD users in permission list. The local "users" group can be removed, if needed. Save.



- While logged-in as admin in ActiNAS GUI, click File Manager. NAS admin account can manage sub-folder permissions. Create sub-folder.




- Select sub-folder, select "Folder" and "Set Folder Permission". Modify permission options in the list. Save.



B. Using domain administrator account

NOTE: The domain administrator account can also be used to Login File Manager.

Log in as admin. Make domain administrator account the owner of the share. Assign other domain users with access permission to the share.



Log in as domain administrator to actiNAS Storage Manager GUI. The File Manager screen will be displayed. Set the sub-folder permission for other domain users (just like in Step 4).

